


DESIG	CP	DRAWN BY	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA		
CHECK	ŒD .	APPROVED	DRAWING NO.	REV. A	
	#	#	DSI 9298	SHEET 1 OF 4	
DATE			TITLE	SCALE	
05.0	4.01		LANDING LIGHT MODIFICATION	NTS	
Α		05.04.01	NEW ISSUE		

## DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS D350-567 Rev.C & SERVICE INSTRUCTION DSI 9282 Rev. A

> REF. CANADIAN STC: SH92-18 ISSUE 5 REF. FAA STC: SH989NE / SH990NE

Contrary to DSI 9282, the D350-567-111 Vertical Reference Window Kit can be made compatible with the 355A64-7047-38 (or equivalent) Landing Light by relocating the light as shown below. Follow the installation procedure on page 2 of this service instruction.



Copyright © 2005 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.



	DESIGN CP	DRAWN BY	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA		
	CHECKED	APPROVED	DRAWING NO.	REV.	A
90	#	#	DSI 9298 SHEET	2 OF	4
	DATE		TITLE	SCAL	Ε
	05.04.01		LANDING LIGHT MODIFICATION	NT	s

#### **MODIFICATION INSTRUCTIONS**

PRIOR TO INSTALLING THE DART D350-567-113 WINDOW KIT ON AIRCRAFT EQUIPPED WITH 355A64-7047-38 (OR EQUIVALENT) LANDING LIGHT, PERFORM THE FOLLOWING MODIFICATION:

#### Remove Hardware:

 Remove the 355A64-7047-38 landing light, associated attachment hardware, 350A21-0024-00A1(or equivalent) fairing, and 350A21-0025-02 (or equivalent) fairing.

#### Fill Existing Landing Light Hole (see Figure 2 for reference):

- (2) Attach a backing plate with release film to outside surface of fairing to match fairing curvature. An aluminum sheet and release film taped on with Teflon tape is recommended.
- (3) For fiberglass modifications in these instructions use the following materials:
  - (i) 9 oz cloth: 9.7 oz. 7781 "S" Glass Universal Weave, OR equivalent.
  - (ii) Adhesive/Resin: EPOCAST 50-A/9816 (CIBA GEIGY), EPOCAST 6121, Macrobond 6398, or Hysol EA9309-3NA / EA9300 / EA9330.3 / EA9359.3
  - (iii) Adhesive paste: Mixture of adhesive, Milled Fibers E-Glass (CIBA GEIGY), and K20 Glass Bubbles (3M), OR 5 minute epoxy, OR equivalent.
- (4) Fill landing light attachment holes with adhesive paste (see Figure 2).
- (5) Lay up 1 layer of 9 oz. cloth on inside surface of fairing, covering part of the cutout and surrounding area shown in Figure 2. Cut and lay up 2 layers of 9 oz. cloth inside the cutout to match the contour in the fairing. Lay up 2 layers of 9 oz cloth to form new inside skin, staggering the size of each cloth, with the final piece covering an area 2" around the cutout. Cure at room temperature for 24 hours.
- (6) Remove the backing plate. Lay up 1 layer of 9 oz. cloth covering and surrounding the newly filled cutout to create a new outside skin. An area 2" around filled cutout should be covered as shown in Figure 1. Cure at room temperature for 24 hours.

#### Install Landing Light at New Location (see Figure 1 & 3 for reference):

- (7) Position the landing light in its new location (see Figure 1). Mark the location of the landing light's outer casing (this may be easier using a template). Remove the casing or template and cut fiberglass 1.00" from edge of landing light casing, as shown in Figure 3.
- (8) Trim foam in a 0.75" perimeter around newly cut hole at a 30° angle and apply 2 layers of 9 oz cloth covering an area 2.0" around the cutout as shown in Figure 3. Cure at room temperature for 24 hours.
- (9) Transfer drill Ø0.250 holes for attachment hardware using landing light casing or a template.
- (10) Touch up paint per the Aircraft Maintenance Manual to match original finish.
- (11) Install D350-567-113 per service instruction DSI 9282 (if not already installed).
- (12) Re-install Landing Light using existing hardware.

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-0-01

APPROVED

BY:

D. SHEPHERD (DE # 02)


DATE:
CERT. NO.:
SH92-18
ISSUE NO.:
5



DESIGN CP	DRAWN BY	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
CHECKET	APPRO\"	DRAWING NO.	REV. A
#	#	DSI 9298	SHEET 3 OF 4
DATE		TITLE	SCALE
05.04.01		LANDING LIGHT MODIFICATION	NTS

# FIGURE 2: FAIRING MODIFICATION, OLD LOCATION

VIEW LOOKING DOWN AT INSIDE OF 350A21-0025-02 (OR EQUIVALENT) FAIRING



### SECTION B-B

VIEW ROTATED 90° CW NOT TO SCALE LAY UP 5 LAYERS OF 9 oz CLOTH AS SHOWN TO FORM 2.0" -NEW INSIDE SKIN **FAIRING** BACKING PLATE SKIN WITH RELEASE FILM 2.0" AFTER INSIDE SKIN CURES LAY UP 1 LAYER OF 9 oz CLOTH TO FORM NEW OUTSIDE SKIN

CANADA DEPARTMENT OF TRANSPORT AIRCRAFT CERTIFICATION **BRANCH** DAO # 01-O-01

**APPROVED** 

D. SHEPHERD (DE # 02)

DATE: CERT. NO .: ISSUE NO .:

05.04.01 SH92-18 5

Copyright © 2005 by DART AEROSPACE LTD


THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.




DESIGN CP	DRAWN BY	DART AEROSPACE HAWKESBURY, ONTARIO, CANA	
CHECKED	APPROVED	DRAWING NO.	REV. A
#	#	DSI 9298	SHEET 4 OF 4
DATE	<b></b>	TITLE	SCALE
05.04.01		LANDING LIGHT MODIFICATION	NTS

# FIGURE 3: FAIRING MODIFICATION. NEW LOCATION

VIEW LOOKING DOWN AT INSIDE OF 350A21-0024-00A1(OR EQUIVALENT) FAIRING





CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-0-01

**APPROVED** 

D. SHEPHERD (DE # 02)

DATE: 05.04.01
CERT. NO.: SH92-18
ISSUE NO.: 5

Copyright © 2005 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.